


Door designs shown are not available in all sizes.



# Standard Designs

Door designs shown are not available in all sizes.

571 572 573 574 575 576 577 578 579 580 581 582 583

584 585 586 587 588 589 590 591 592 593 594 595 596

597 598 599 600 601 602 603 604 605 606 607 608 609

610 611 612 613 614 615 616 617 618 619 620 621 622

623 624 625 626 627 628 629 630 631 632 633 634 635

636 637 638 639 640 641 642 643

644 645 646 901/951 902/952 912/962 801 802

LOUVERS AND FALSE LOUVERS BEAD BOARD OPTION

**KEY**

<b>Infinity Standard Molding</b>	1000 series
<b>Infinity Architectural</b>	2000A series
<b>Infinity Designer</b>	2000D series
<b>Encore</b>	6000 series
<b>Ovation</b>	7000 series
<b>Bravo</b>	4000 series

Use one of the "series" numbers above to define what product line of door you want along with the door design of your choice. **Example:** #1101 would be an Infinity 101 square top, one panel with standard moulding.

**Blue lines** on door designs indicate additional stile and rail joint detail that will only be present on Bravo Traditional Stile and Rail constructed doors.

**Red numbers** indicate door designs that are *not* available in the Bravo line.